



**BLONDER TONGUE**  
L A B O R A T O R I E S

## Uplink Configuration for the CMTS Edge 16

Field Notice  
May 27, 2022



## Overview

Before the CMTS Edge 16 is deployed with the 1-Gigabit Ethernet SFP module it is shipped with, the Uplink Port of the CMTS must be configured to expect and recognize the 1-Gigabit Ethernet Copper SFP that is shipped with the unit.

## Procedure

These are the steps to configure the CMTS Edge 16 to recognize a 1 Gigabit SFP module.

1. Connect a personal computer to the CMTS Edge Console port with a serial cable.
2. Log into the CMTS with the following credentials (factory defaults shown below) or the current credentials if you have changed them from the factory defaults:

username: **admin**  
password: **admin**

3. At the system prompt, type the command "**enable**" to enter privileged mode.
4. At the system prompt, enter the following commands:

```
conf t  
int uplink 1  
phy ge
```

5. At this point you will see the following message that the CMTS will reboot after you confirm by pressing "**y**":

Uplink mode change will request system reboot, continue?(y/n) [n]

6. After the CMTS System has rebooted, at the system prompt, log into the CMTS with the same credentials as above.

7. At the system prompt, enter the command "**enable**".

8. Enter the following commands to ensure that the CMTS is expecting a 1Gigabit Ethernet SFP module:

```
conf t  
int uplink 1  
show phy
```

The show phy command output should show that the Media is "GE":

Interface	Media	LinkStatus	Speed(Mbps)	DuplexMode	Description
1	GE	Down	1000	Full	

NOTE: Once you connect the CMTS uplink SFP to a network device and the interface is operational, the LinkStatus column will show the value of "Up".

The CMTS is now expecting that a 1-Gigabit Ethernet copper SFP will be installed and your network connections will work as expected.