

# **BTPRO-8000S**

PROFESSIONAL SATELLITE, TV, CATV & OPTICAL ANALYZER



### **KEY FEATURES**

- » Auto Discovery System automatically detects and selects analog and digital COFDM/QAM TV signals in both Measurement and Spectrum modes
- » Help Function automatically identifies all the signals with digital modulation – SAT, TV, and CATV
- » Digital Measurements include Digital Power, MER, BER, PER, LDPC, BCH, Noise Margin, MER vs Carrier
- » Automatic Assistant provides Signal Quality analysis, Channel Scan memorization
- » Barscan TV & CATV Function tests from 10 to 100 channels on one (1) screen
- » Buzzer & Noise Margin provided via real time graph
- » USB on the Go for long-term logging and storage
- » Remote Monitoring and Control
- » Memory Functions Supported Auto, Manual, Logger

## **PRODUCT OVERVIEW**

The **BTPRO-8000S** is a professional HD Tablet/Touch Analyzer with a frequency range of 4 to 2610 MHz. The analyzer features a 7-inch 16:9 color display touchscreen, is lightweight, and compact in size.

The **BTPRO-8000S** is ideal for analyzing and logging in the lab or out in the field — HD/SD QPSK/8PSK Satellite, COFDM, QAM, NTSC, as well as Fiber Optics and Wi-Fi Signals.

### ORDERING INFORMATION


MODEL	STOCK#	DESCRIPTION
BTPRO-8000S	4232 S	HD Tablet/Touch Signal Analyzer

# BTPRO-8000S

**SPECIFICATIONS** 




GENERAL					
Dimensions (W x H x D)	1004 x 1.6 x 5.12 in (255 x 41 x 130 mm)				
Weight	3.09 lbs (1.4 kg)				
Display	7" TFT touch display, 16:9, high res				
Battery	Li-Po battery pack; 2-hour duration				
USB PC Interface	For storage memory stick				
Supplies	Power supply & Battery charger – 12VDC – 1A				
Housing	Metal box and padded transport bag				



Wide Band Measure and Spectrum - Compatible with newer systems, the Wide Band LNB is capable of measuring full band of 230-2340 MHz.

PLAN	MODULAT	BW	DC@RF	FREQ	CHAN
AUTO 1	T	8	OFF	690.00	48
6 8 8 8 7 8 8 7 8 8 7 8	# # # # # # # # # # # # # # # # # # #		INFO CARRIE CONST: GUA.INT	R:	8K DVB-T 64QAM 1/4 3/4 3/4
* * *	* * * * * * *		HIER. :		3/4 3/4 NO
			LNB Cu	rr:	0mA
TSID:	: 512 CI	D: 5038	(0x13AB)		♠ MENU

**Constellation Diagram**— For Satellite, TV, and CATV signals



**Satellite Finder**— Users can simultaneously check the quality of up to four (4) satellite transponders, and can check the correct function of the LNB in all polarities.



**Measure and Picture** — MPEG-2/4 SD & HD picture with Program List, Audio Video PIDS, LCN, Video Bit Rate all on one screen