AP Switch Settings, HRC Output

(Black Bar Indicates Switch Position)

CH	EIA CH	NOMINAL PIX	OFFSET PIX	L.O.	SWITCH 1								SWITCH 2									
					1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	9	10
2	2	54		667														X	X	X	X	
3	3	60		673														X	X	X	X	
4	4	66		679														X	X	X	X	
A-8	1	72		685														X	X	X	X	
5	5	78		691														X	X	X	X	
6	6	84		697														X	X	X	X	
A-5	95	90		703														X	X	X	X	
A-4	96	96		709														X	X	X	X	
A-3	97	102		715														X	X	X	X	
A-2	98	108	108.0250	721														X	X	X	X	
A-1	99	114	114.0250	727														X	X	X	X	
A	14	120	120.0125	733														X	X	X	X	
B	15	126	126.0125	739														X	X	X	X	
C	16	132	132.0125	745														X	X	X	X	
D	17	138		751														X	X	X	X	
E	18	144		757														X	X	X	X	
F	19	150		763														X	X	X	X	
G	20	156		769														X	X	X	X	
H	21	162		775														X	X	X	X	
I	22	168		781														X	X	X	X	
7	7	174		787														X	X	X	X	
8	8	180		793														X	X	X	X	
9	9	186		799														X	X	X	X	
10	10	192		805														X	X	X	X	
11	11	198		811														X	X	X	X	
12	12	204		817														X	X	X	X	
13	13	210		823														X	X	X	X	
J	23	216		829														X	X	X	X	
K	24	222		835														X	X	X	X	
L	25	228	228.0125	841														X	X	X	X	
M	26	234	234.0125	847														X	X	X	X	
N	27	240	240.0125	853														X	X	X	X	
O	28	246	246.0125	859														X	X	X	X	
P	29	252	252.0125	865														X	X	X	X	
Q	30	258	258.0125	871														X	X	X	X	
R	31	264	264.0125	877														X	X	X	X	
S	32	270	270.0125	883														X	X	X	X	
T	33	276	276.0125	889														X	X	X	X	
U	34	282	282.0125	895														X	X	X	X	
V	35	288	288.0125	901														X	X	X	X	
W	36	294	294.0125	907														X	X	X	X	

XXXX = ▭▭▬▭ For Off-Channel(Input Channels differ from Output Channels) Operation

▭▭▬▭ For On-Channel(Input Channels Same as Output Channels) Operation, Option 14 not in use

NOTE: For On-Channel Operation, turn OFFSET ADJ fully clockwise

AP Switch Settings, HRC Output

(Black Bar Indicates Switch Position)

CH	EIA CH	NOMINAL PIX	OFFSET PIX	L.O.	SWITCH 1								SWITCH 2									
					1	2	3	4	5	6	7	8	1	2	3	4	5	6	7	8	9	10
AA	37	300	300.0125	913	▭	▬	▬	▬	▭	▬	▬	▭	▭	▭	▬	▭	▬	X	X	X	X	▬
BB	38	306	306.0125	919	▭	▭	▭	▬	▭	▬	▬	▭	▭	▭	▬	▭	▬	X	X	X	X	▬
CC	39	312	312.0125	925	▭	▬	▭	▭	▭	▬	▬	▭	▭	▭	▬	▭	▬	X	X	X	X	▬
DD	40	318	318.0125	931	▭	▭	▬	▬	▬	▭	▬	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
EE	41	324	324.0125	937	▭	▬	▬	▭	▬	▭	▬	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
FF	42	330	330.0250	943	▭	▭	▭	▭	▬	▭	▬	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
GG	43	336	336.0125	949	▭	▬	▭	▬	▭	▭	▬	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
HH	44	342	342.0125	955	▭	▭	▬	▭	▭	▭	▬	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
II	45	348	348.0125	961	▭	▬	▬	▬	▬	▬	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
JJ	46	354	354.0125	967	▭	▭	▭	▬	▬	▬	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
KK	47	360	360.0125	973	▭	▬	▭	▭	▬	▬	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
LL	48	366	366.0125	979	▭	▭	▬	▬	▭	▬	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
MM	49	372	372.0125	985	▭	▬	▬	▭	▭	▬	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
NN	50	378	378.0125	991	▭	▭	▭	▭	▭	▬	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
OO	51	384	384.0125	997	▭	▬	▭	▬	▬	▭	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
PP	52	390	390.0125	1003	▭	▭	▬	▭	▬	▭	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
QQ	53	396	396.0125	1009	▭	▬	▬	▬	▭	▭	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
RR	54	402		1015	▭	▭	▭	▬	▭	▭	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
SS	55	408		1021	▭	▬	▭	▭	▭	▭	▭	▭	▭	▭	▬	▭	▬	X	X	X	X	▭
TT	56	414		1027	▭	▭	▬	▬	▬	▬	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
UU	57	420		1033	▭	▬	▬	▭	▬	▬	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
VV	58	426		1039	▭	▭	▭	▭	▬	▬	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
WW	59	432		1045	▭	▬	▭	▬	▭	▬	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
XX	60	438		1051	▭	▭	▬	▭	▭	▬	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
YY	61	444		1057	▭	▬	▬	▬	▬	▭	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
ZZ	62	450		1063	▭	▭	▭	▬	▬	▭	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
AAA	63	456		1069	▭	▬	▭	▭	▬	▭	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
BBB	64	462		1075	▭	▭	▬	▬	▭	▭	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
CCC	65	468		1081	▭	▬	▬	▭	▭	▭	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
DDD	66	474		1087	▭	▭	▭	▭	▭	▭	▬	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
EEE	67	480		1093	▭	▬	▭	▬	▬	▬	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
FFF	68	486		1099	▭	▭	▬	▭	▬	▬	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
GGG	69	492		1105	▭	▬	▬	▬	▭	▬	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
HHH	70	498		1111	▭	▭	▭	▬	▭	▬	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
III	71	504		1117	▭	▬	▭	▭	▭	▬	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
JJJ	72	510		1123	▭	▭	▬	▬	▬	▭	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
KKK	73	516		1129	▭	▬	▬	▭	▬	▭	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
LLL	74	522		1135	▭	▭	▭	▭	▬	▭	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
MMM	75	528		1141	▭	▬	▭	▬	▭	▭	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
NNN	76	534		1147	▭	▭	▬	▭	▭	▭	▭	▬	▬	▬	▭	▭	▬	X	X	X	X	▭
OOO	77	540		1153	▭	▬	▬	▬	▬	▬	▬	▭	▬	▬	▭	▭	▬	X	X	X	X	▭
PPP	78	546		1159	▭	▭	▭	▬	▬	▬	▬	▭	▬	▬	▭	▭	▬	X	X	X	X	▭

XXXX = ▭ ▭ ▬ ▭ For Off-Channel(Input Channels differ from Output Channels) Operation

▭ ▭ ▬ ▭ For On-Channel(Input Channels Same as Output Channels) Operation, Option 14 not in use

NOTE: For On-Channel Operation, turn OFFSET ADJ fully clockwise